# Meet your phone.

verizon<sup>4</sup>

## About your phone



# Setting up your phone


Your phone already has a SIM card installed.

**Optional:** Insert the microSD card 1. With the phone's screen facing up, insert the tool that came with your phone into the hole on the SIM/microSD card tray to partially eject the tray. Then, carefully pull the card tray out.

 Insert the microSD card with the gold contacts facing down and toward the phone (as shown below).

3. Carefully insert the card tray back into the slot and close it.

NOTE: The microSD card is sold separately.



#### Charge your phone

Before turning on your phone, charge it fully.

Your phone comes with an fast charging charger and a USB Type-C cable. Plug one end of the USB Type-C cable to the USB/ charger port (as shown below) and the other end into the charger. Then plug the charger into an outlet.



Para la versión en español, visite verizonwireless.com/Support

LG G<sup>6</sup>

NOTE: Devices and software are constantly evolving-the screen images and icons you see here are for reference only. WARNING: Only use approved chargers with your device. Incompatible chargers or tampering with the charger port could damage your device and void the warranty.

## Using your phone

#### Turning your phone on/off

To turn your phone on, press and hold the **Power/Lock** button.

To turn it off, press and hold the **Power/Lock** button. Then tap **Power off** > **POWER OFF**.

#### Locking/unlocking the screen

To turn on your screen, press the **Power/Lock** button. Then swipe up on the screen to unlock it.

To turn off your screen and prevent accidental key presses, press the **Power/Lock** button.

#### Home screen mode

You can select one of 3 modes:
Home (default): Provides a basic layout and settings for apps and widgets.
EasyHome: Provides a simplified experience for the first-time smartphone user.
Home with separate apps list: Provides a separate layout for the Home screen and apps list.

Instructions in this guide are written for Home mode.

 From the Home screen, swipe left (if necessary); then tap Settings > Home screen > Select Home.
 Choose the mode you want to use.

Copying content from your old phone For help transferring contacts, photos and other content from your old phone, visit verizonwireless.com/Cloud.

## Learning more

The Help app gives you tips and other information on how to use your phone, including:

Making calls

Voicemail

Sending texts

Getting apps

Taking photos

Accessibility settings

From your computer, visit verizonwireless.com/Support.

Download a User Guide from verizonwireless.com/Support.

### **Managing your account**

My Verizon Mobile app Manage your account, track your usage, edit account information, pay your bill and more.

> International travel For features and rates when outside the US, visit verizonwireless.com/ International.

Customer service Call 800.922.0204 Twitter @VZWSupport

# **Additional information**

#### Your wireless device and third-party services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms, conditions and policies prior to using this wireless device and any associated application, product or service.

#### Hearing aid compatibility information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer technologies that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Ask your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, ask your service provider or phone retailer.

MBM65758701 (1.0) H

A This booklet is made from 100% post-consumer recycled paper.
 EVENTRY
 This booklet is printed with soy ink. Printed in Korea

LG and G6 is a trademark of LG Electronics, Inc. Google, Android, and the Google Play is trademarks of Google Inc.